### Installation and use of the CPP SDK

PN146 | Posted on March 26, 2021 | Updated on August 8, 2025



Benoît STEINMANN Software Team Leader imperix • in

#### **Table of Contents**

- Software installation
- <u>User template retrieval</u>
- Code edition
  - o Folders organization
  - Renaming the project
  - Specifying the number of devices used
- Code compilation
- Loading the code into the device
- Further readings

This note describes how to install and get started with the imperix C++ Software Development Kit (SDK).

### **Software installation**

After registration, the installer of the C++ SDK can be downloaded directly from imperix's website, under **Support**  $\rightarrow$  **Downloads**.

Download link: <a href="https://imperix.com/downloads">https://imperix.com/downloads</a>


Download the latest version (CPPSDK\_Setup\_xxxx.x.exe), execute the installer, and follow the instructions.

When asked by the installer, it is recommended to keep the default destination folder C:\imperix\BB3\_CPP\_SDK and to avoid spaces or special characters in the pathname.


### **User template retrieval**

To launch the imperix C++ IDE, search for "imperix C++ IDE" in the Windows start menu and click on it, or use the desktop shortcut. The first launch of the IDE can be slower because Eclipse sets up the environment and makes some configuration.

The IDE will then ask for a workspace directory. The workspace is the location in your file system where Eclipse stores its preferences and other resources. Chose your workspace folder and click on **Launch**.




Once launched, the Eclipse environment will look like the following screenshot.




The first step is to retrieve the base source code from the root of the installation directory (by default located at

#### C:\imperix\BB3\_CPP\_SDK\BB3\_CPP\_Template.zip)


#### Select File -> Import...



#### Under General, select Existing Projects into Workspace and click Next



Check the box **Select archive file** and browse the installation directory to find the zip file BB3\_CPP\_Template.zip and click on **Finish** 



The same procedure applies to import code examples provided by imperix.

## **Code edition**

# Folders organization

The picture below shows the coding environment of the imperix C++ IDE. The project template contains several folders (as shown in the Project Explorer on the left), which are organized as follows.

**My\_functions** is the folder where all user files should be stored. By default, it contains only two files that the user can freely modify:

- user.h, which typically contains the prototypes of the user-defined routines as well
  - as some data types definitions.
- user.cpp, which serves as the code root and contains the initialization and main interrupt
  - service routines used to control the application.

```
DE imperix-cpp-workspace - BB3_CPP_Template/My_functions/user.cpp - imperix C++ IDE
<u>File Edit Source Refactor Navigate Search Project Run Window Help</u>
 🔦 📳 External Tools 🗸 💁 Cockpit
                                                                                                                                                                                              ☆ ▼ ② ▼ ♀ □ ▼ □ ▼ □ Ø □ ¶ ■ ■ ■ ■ ■ ■ ■ ■ ▼ □ ▼ □ ▼ □ ▼ □ ▼
                                                                                                                                                                                                                                                                                                                                         Quick Access : 😭 📴
🊹 Project Explorer 🌣 📄 🥞 🤝 ▽ 🗆 🗖 🚺 user.cpp 🌣

✓ 

BB3_CPP_Template

                                                                                                                                   #include "user.h"
       > 🔆 Binaries
                                                                                                                              2
3⊖ /**
4 * Global variables
                                                                                                                                                                                                                                                                                                                                                                                               > 🔊 Includes
                                                                                                                                                                                                                                                                                                                                                                                               •
        > 🗁 API
         > 👝 Debug
                                                                                                                              6 float Vdc meas = 0;
                                                                                                                                                                                                                // Measured DC bus voltage
      8 tUserState currentState = STANDBY;
9 tUserState nextState = STANDBY;
             > c user.cpp
               > lin user.h
            Cockpit.launch
                                                                                                                          110/**

Initialization routine executed only once, before the first call of the main inter

To be used to configure all needed peripherals and perform all needed initializat:

To be UserSafe UserInit(void)

16 {

17 }

18 | 18 | 18 |

19 | 18 |

10 | 18 |

10 | 18 |

10 | 18 |

10 | 18 |

10 | 18 |

10 | 18 |

10 | 18 |

10 | 18 |

10 | 18 |

11 | 18 |

12 | 18 |

13 | 18 |

14 | 18 |

15 | 18 |

16 | 18 |

17 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18 |

18 | 18
             howtorename.txt
                                                                                                                                               /**

** Configuration of the main interrupt.

* - The frequency of clock 0 is set to the desired switching frequency


* - The main interrupt routine is mapped on clock 0 with a phase of 0.5.

* - As the the sampling of the ADC channels happens just before the interrupt i:

* setting a phase of 0.5 allows to sample in the middle of each switching per:


*//
                                                                                                                           18
                                                                                                                                                Clock_SetFrequency(CLOCK_0, SW_FREQ);
ConfigureMainInterrupt(UserInterrupt, CLOCK_0, 0.5);
                                                                                                                                     CDT Build Console [BB3_CPP_Template]
"C:\\imperix\\BB3_CPP_SDK\\GnuWin32\\bin\\make" -j8 all make: Nothing to be done for `all'.
                                                                                                                     11:01:55 Build Finished, 0 errors, 0 warnings, (took 190ms)
                                                                                                                                                                                                 Smart Insert 1:1
```

The **Includes** folder contains the headers of the corresponding user-accessible routines. By browsing the includes, the user can get a quick overview of the available peripheral driver routines, as well as all the necessary information regarding their use.



The **API** folder contains ready-to-use routines that are popular in power electronic applications (controllers, coordinate transformations, PLLs, data structures, etc...).

Users are recommended to use these predefined routines. If necessary, these routines can be modified.




The **Debug** folder contains all the files produced by the compilation of the project.

**Cockpit.launch** and **makefile.defs** are configuration files, they should not be modified.

## Renaming the project


To rename the project, the following procedure should be followed. Due to an <u>Eclipse bug</u>, not following the procedure will lead to a <u>resource is out of sync with the file system</u> error.

- 1. Right-click on the project, click **Rename...** (or press F2), and enter the new
- 2. Right-click on the project and click **Properties** (or press Alt+Enter)
- 3. Click on C/C++ Build and select the Refresh Policy tab
- 4. Delete the resource with the old project name
- 5. Click **Add Resource...** and select the folder with the name of the project and click **OK**
- 6. Click Apply and Close



# Specifying the number of devices used

Since SDK 2025.1, as shown on the image below, Cockpit reads how many devices are used by the user code to properly display the assignment between the user code (project) and targets.




When using the <u>ACG SDK</u>, the number of used devices is automatically retrieved. With the C++ SDK however, users must explicitly specify this information using the NUMBER OF DEVICES macro, as illustrated below.

```
user.cpp 

1 #include "user.h"
2
3 NUMBER_OF_DEVICES(2);
4
5⊖ /**
6 * Global variables
```

Alternatively, this information can be manually edited from Cockpit, using the *No. of devices* field.



If the Eclipse IDE underlines the NUMBER\_OF\_DEVICES in orange, please try the following:

Right-click on the project → Index → Rebuild

### **Code compilation**

By default, the code is automatically rebuilt each time that the user saves a file. This behavior can be changed by going to  $Project \rightarrow Properties \rightarrow C/C++$  Build  $\rightarrow$  Behavior tab and unchecking Build on resource save


The compilation can be manually launched by clicking on the "Build" icon at the top left corner of the IDE, or by pressing "CTRL+B". The console window displays build information as well as any errors. The executable is generated in the "debug" folder (.elf file)

# Loading the code into the device

The code upload and flashing are handled by the <u>imperix Cockpit</u> utility software. The easiest way to launch Cockpit is to select your project and click on the "run" icon, directly within imperix C++ IDE SDK shown on the screenshot below. Cockpit opens automatically and loads the executable on the connected B-Box RCP or B-

Board PRO.

Related getting-started instructions are available in <u>Programming and operating imperix controllers</u>.



## **Further readings**

- Programming and operating imperix controllers (PN138)
- Cockpit User guide (PN300)
- CPP SDK troubleshooting (PN147)