

TRQ - Torque sensor

SD105 | Posted on November 8, 2021 | Updated on May 27, 2025



Simon STROBL

Product Director

imperix • in

Table of Contents

- [Simulink block](#)
 - [Signal specification](#)
 - [Parameters](#)
- [PLECS block](#)
 - [Signal specification](#)
 - [Parameters](#)
- [C++ functions](#)

The torque sensor (TRQ) block reads the voltage output of a torque sensor and converts it to torque. It targets drive applications.

The B-Box RCP supports a single torque sensor through the [Motor Interface for B-Box RCP](#). The sensor's output must be a voltage proportional to the applied torque. The TRQ block will then read the input voltage and convert it to torque, using the specified sensitivity and offset of the sensor.

The TRQ block is available starting from [version 3.7.1.4](#) of the SDK. The Motor Interface for B-Box RCP is **required** to use this driver.

Simulink block


Signal specification

- The output signal is the measured torque in [Nm].
- The `sim` input signal is used in simulation and represents the actual torque, computed by the simulation plant model.
- The `>` input signal needs to be connected to the sampling clock generated by the [CONFIG block](#) to account for the exact sampling instant in simulation.



Parameters


- Device ID selects which B-Box/B-Board to address when used in a multi-device configuration.
- Sensor sensitivity [V/Nm] defines the sensitivity of the sensor.
- Sensor offset [V] defines the voltage offset of the sensor.



PLECS block


Signal specification


- The output signal is the measured torque in [Nm].
- The `sim` input signal is used in simulation and represents the actual torque, computed by the simulation plant model.
- The `>` input signal needs to be connected to the sampling clock generated by the [CONFIG block](#) to account for the exact sampling instant in simulation.



Parameters

- `Device ID` selects which B-Box/B-Board to address when used in a multi-device configuration.
- `Sensor sensitivity [V/Nm]` defines the sensitivity of the sensor.
- `Sensor offset [V]` defines the voltage offset of the sensor.





C++ functions

MotInt_EnableMotorInterface — Enable the drivers of the Motor Interface

```
void MotInt_EnableMotorInterface(unsigned int device=0);Code language: C++ (cpp)
```

Enable the drivers of the Motor Interface.

It has to be called in `UserInit()`.

Parameters

- `device`: the id of the addressed device (optional, used in multi-device configuration only).

Trq_AdjustSensorParams — Adjust the sensor parameters

```
void Trq_AdjustSensorParams(float sensitivity, float offset, unsigned int device=0);Code language: C++ (cpp)
```

Adjusts the sensitivity and offset of the sensor for calibration purposes.

It has to be called in `UserInit()`.

Parameters

- `sensitivity`: defines the sensitivity of the sensor in [V/Nm]
- `offset`: defines the offset of the sensor in [V]
- `device`: the id of the addressed device (optional, used in multi-device configuration only).

Trq_GetTorque — Get the torque

```
float Trq_GetTorque(unsigned int device=0);Code language: C++ (cpp)
```

Gets the torque measurement in [Nm].

It has to be called during the control interrupt.

Parameters

- `device`: the id of the addressed device (optional, used in multi-device configuration only).